



1. Fold tabs A and B up.
2. Insert through C hole in wheel..
3. Insert this group through D
4. Fold tabs down & glue ● to A and B in the bookmark above.
5. Glue E over to hide the cam
6. Glue tabs of the bookmark above and fold over to hide the wheel and cam assembly.

